

Supported Languages for Pepper Robot

Version 06/2018

Supporting ALTextToSpeech,
ALSpeechRecognition

Locate	Language Name	Dialog code	Tools	Content and Samples	Notifications	ASR Engine	TTS Engine	Activity Launcher	Conversation	Remote ASR Engine
			Choreographe		NAOqi API		Basic Channel	Remote		
ja_JP	Japanese	jpj	OK	OK	OK	OK	AiTalk	OK	OK	OK
en_US	Englisch	enu	OK	OK	OK	OK	Nuance	OK	OK	OK
fr_FR	French	frf	OK	OK	OK	OK	Nuance	OK	OK	X
it_IT	Italian	iti	OK	OK	OK	OK	Nuance	OK	X	X
de_DE	German	ded	OK	OK	OK	OK	Nuance	OK	X	X
es_ES	Spanish	spe	OK	OK	OK	OK	Nuance	OK	X	X
zh_CN	Chinese	mnc	OK	OK	OK	OK	Nuance	OK	X	OK
zh_TW	Mandarin Taiwan	mnt	OK	OK	X	OK	Nuance	OK	X	OK
nL_NL	Dutch	dun	OK	OK	Partial/Not	OK	Nuance	Partial/Not	X	X
ar_SA	Arabic	arw	OK	OK	Partial/Not	OK	Nuance	Partial/Not	X	X
ko_KR	Korean	kok	OK	OK	Partial/Not	X	X	Partial/Not	X	X
pL_PL	Polish	plp	OK	OK	Partial/Not	X	X	Partial/Not	X	X
pt_BR	Brazilian	ptb	OK	OK	Partial/Not	X	X	Partial/Not	X	X
pt_PT	Portuguese	ptp	OK	OK	Partial/Not	X	X	Partial/Not	X	X
cs_CZ	Czech	czc	OK	OK	Partial/Not	X	X	Partial/Not	X	X
da_DK	Danish	dad	OK	OK	Partial/Not	X	X	Partial/Not	X	X
fi_FI	Finnish	fif	OK	OK	Partial/Not	X	X	Partial/Not	X	X
sv_SE	Swedish	sws	OK	OK	Partial/Not	X	X	Partial/Not	X	X
ru_RU	Russian	rur	OK	OK	Partial/Not	X	X	Partial/Not	X	X
tr_TR	Turkish	trt	OK	OK	Partial/Not	X	X	X	X	X
nn_NO	Norwegian	nor	OK	X	Partial/Not	X	X	X	X	X
eL_GR	Greek	grg	OK	X	Partial/Not	X	X	X	X	X

	OK
	Partial/Not
	Not Supported Yet